

ASSEMBLY INSTRUCTIONS SURFACE MOUNT FLAT BENCH

STEP 1: PLACE THE 2 (OR 3 DEPENDING ON MODEL) SURFACE MOUNT LEGS FACING UPRIGHT ON A LEVEL SURFACE SO THE MOUNTING BRACKETS ARE FACING TOWARD THE INSIDE. (ESTIMATE SPACING).

STEP 2: PLACE A 4" X 4" PROFILE OVER ONE OF THE 2 INSIDE SET OF HOLES ON THE SURFACE MOUNT LEGS, MAKING SURE THE "MOLD" SEAM IS FACING DOWN.

STEP 3: SLIDE PROFILE TO ALIGN HOLES WITH THE CORRESPONDING HOLES OF THE SURFACE MOUNT LEGS.

STEP 4: INSERT BOLTS THROUGH EACH HOLE IN THE PROFILE INTO THE SURFACE MOUNT LEGS. PLACE A FLAT WASHER AND FLANGE NUT ONTO THE BOTTOM OF EACH BOLT – **HAND TIGHTEN ONLY.**




STEP 5: PLACE THE REMAINING 4" X 4" PROFILES ON THE SURFACE MOUNT LEGS, MAKING SURE THE "MOLD" SEAM IS FACING DOWN. REPEAT STEPS 3 & 4.

STEP 6: ONCE ALL BOLTS, WASHERS, AND NUTS ARE IN PLACE, TIGHTEN BOLTS SECURELY WITH A 3/8" DRIVE RATCHET WITH A 1/2" DEEP WELL SOCKET (SHIFTING YOUR BENCH WHERE NECESSARY TO INSURE A NEAT SQUARE APPEARANCE).

OPTIONAL: THE BENCH CAN BE SECURED TO EITHER CONCRETE OR ASPHALT WITH FOUR STANDARD 1/2" MASONRY FASTENING DEVICES (NOT INCLUDED) USING THE MOLDED-IN METAL BRACKETS ON THE BOTTOM OF THE SURFACE MOUNT LEGS.

NOTE: PROFILES MAY BE DIRECTIONAL
AND YOU MAY NEED TO TURN THEM END-FOR-END IF THEY DO NOT LINE UP SQUARELY.

*Your 100% recycled plastic park bench will give you many years of pleasure and pride,
knowing that you did your part in keeping plastic waste out of landfills and protecting our environment.*

	4'	6'	
REF#	QTY	QTY	DESCRIPTION
1	2	3	SURFACE MOUNT BENCH END
2	4		4" X 4" X 4' PROFILE
2		4	4" X 4" X 6' PROFILE
			HARDWARE KIT
3	8	12	 5/16" X 7" CARRIAGE BOLT
4	8	12	 5/16" FLAT WASHER
5	8	12	 5/16" FLANGE NUT

