

ASSEMBLY INSTRUCTIONS SURFACE MOUNT TRAIL BENCH



STEP 1: PLACE THE 2 (OR 3 DEPENDING ON MODEL) SURFACE MOUNT LEGS ON A LEVEL SURFACE. (ESTIMATE SPACING).

STEP 2: PLACE A 3" X 4" PROFILE OVER THE INSIDE SET OF HOLES ON THE SURFACE MOUNT LEGS, MAKING SURE THE "MOLD" SEAM IS FACING DOWN.

STEP 3: SLIDE PROFILE TO ALIGN PILOT HOLES WITH THE CORRESPONDING HOLES OF THE SURFACE MOUNT LEGS.

STEP 4: FASTEN THE BOARD TO EACH BENCH END FROM THE UNDERSIDE OF THE BENCH ENDS USING 6 OF THE 3" LAG SCREWS & WASHERS PER BENCH END.

STEP 5: REPEAT FOR REMAINING 3 X 4'S.

	4'	6'	
REF#	QTY	QTY	DESCRIPTION
1	2	3	BENCH END
2	3		3" X 4" X 4' PROFILE
2		3	3" X 4" X 6' PROFILE
3	12	18	HARDWARE KIT  3/8" X 3" LAG SCREW  3/8" FLAT WASHER
4	12	18	

NOTE: PROFILES MAY BE DIRECTIONAL
AND YOU MAY NEED TO TURN THEM END-FOR-END IF THEY DO NOT LINE UP SQUARELY.

*Your 100% recycled plastic park bench will give you many years of pleasure and pride,
knowing that you did your part in keeping plastic waste out of landfills and protecting our environment.*

