

INSTALLATION INSTRUCTIONS FOR OUTDOOR SHOWER

Prior to installation:

- ❖ Read all instructions and refer to local codes.
 - ❖ Supply line must be flushed of all foreign materials such as pipe dope, chips, etc.
 - ❖ Piping must be drained prior to being subjected to freezing temperatures.
- 1.) Refer to rough-ins for supply location.
 - 2.) Mount anchoring hardware, by others, onto the base plate.
 - 3.) Install shower to supply line with wooden supports and ensure the bottom of the base plate is flush with the floor and shower head is in the desired location.
 - 4.) Pour concrete until it is even with the bottom of the base plate.

