

LK04-1000 Portable Restroom Door Lock Kit

General Overview

The **LK04 -1000 Door Lock Kit** is designed to be used with most portable restrooms. This kit can be mounted anywhere along the non-hinged side of the door and door jamb. The hasps are made from stainless steel and the rivets are aluminum, assuring a no rust maintenance free long life. Fasteners supplied with kit are designed to be used with doors made with steel pillars and jambs of aluminum. Alternative fasteners may be necessary if used with doors and jambs made of other construction.




The recommended padlock is the **PC-000205M** sold separately.

We recommend reading through the entire information booklet prior to proceeding with installation, service and maintenance. All references to left and right throughout the booklet are as viewed from the front of the restroom.

~~Tools Required~~

- Drill
- 13/64" Drill Bit
- Rivet Gun

Full Size Scale Fasteners



(3) PC-000102 Rivet

(2) PC-000104 Rivet

Lock Installation

One person can install this kit quite easily. It is suggested to install the kit just below the door pull (*as shown below on the PJN3*). Install the crescent plate hasp first.

Step 1. Using the three-holes of the crescent plate hasp as a drill guide, position the plate on the outer lip on the edge of the door, making sure the flat edge is held tight to the door lip.

Step 2. Drill three 13/64" holes into the inner door pillar.

Step 3. Rivet in place using (3) PC-000102 rivets.

Step 4. Now, align the "L" hasp on the edge of the door jamb so that the hole is at the center of the curved slot of the crescent hasp.

Step 5. Using the two-holes of the "L" hasp as a drill guide, drill two 13/64" holes into the door jamb.

Step 6. Rivet in place using (2) PC-000104 rivets.

