


49 Gallon Recycle Center

For Fastener Pack
(FP-RT49-CU-02)



Congratulations ! !


You have just purchased the finest recycled plastic
recycle center available. Enjoy ! ! !

Before assembly, please make sure all components are included.




(1) - One Fastener Pack
FP-RT49-CU-02

(1) - One Circular Lids w/ lanyard
RT-RT49-D-01




(1) - One 49 gal. Liner
S7851-00-159




F

(4) - Four Quarter Panels
RTSA-RT49-QP-02



(4) - Four Side Boards
RT-RT49-B-02




Before assembly, please make sure all fasteners are included.

16 - #12 x 2-1/2" Pan Head Phillips Screw




Also needed for this assembly will be the following materials:


1 - #3 Phillips Drive Bit




Step 1: Take Panel A and place it in the vertical position, align a Panel B in the vertical position making sure the rail aligns with the top and the bottom. Slide the rails in a downward motion until they are even. Make sure the holes in the rails are aligned.




Step 2: Take Panel C and place it in the vertical position, aligning it with the previous Panels. Slide the rail of the panel in a downward motion and align the holes in the rail.



Step 3: Take Panel D and place it in the vertical position, aligning it with the previous Panels. Slide the rail of the panel in a downward motion and align the holes in the rail.




Step 4: Place boards G in the alignment shown above with the top and bottom rails carefully aligning the holes in the rails with the pilot holes in board G. Once you have the holes aligned insert (1) - One #12 x 2-1/2" Pan Head Phillips Screw per hole. Make sure both screws are all the way in and tight on the top rail once you have gone all the way around the top rail flip the trash can up side-down-and repeat the previous steps to complete the bottom rail. (Note: Please be careful to not over tighten the screws.)



Step 5: If you would like to take advantage of the supplied Lid Lanyard, just remove the desired screw from the top rail and re-secure it with the lanyard attached.

(Just remove the screw in the lid if you would like to forgo the use of the Lid Lanyard.)

Step 6: Finally, put the liner in the receptacle as shown and place the lid on the top rail with the lanyard on the underside (if attached).



DEAR VALUED CUSTOMER,

THANK YOU FOR PURCHASING THIS
PRODUCT. THIS PRODUCT IS
MANUFACTURED USING RECYCLED
MATERIALS AND MAY HAVE SLIGHT
COLOR VARIATIONS, OCCASIONAL
SPECKS OF COLOR OR IRREGULAR
SURFACE PATTERNS. THESE ARE
NORMAL CONDITIONS OF RECYCLED
PLASTICS AND MAKE EACH PIECE OF
FURNITURE UNIQUE. THESE
CHARACTERISTICS DO NOT AFFECT
THE STRENGTH, QUALITY OR
PERFORMANCE OF THE PRODUCT.

THANK YOU AGAIN FOR PURCHASING
THIS PRODUCT AND HELPING OUR
ENVIRONMENT.