


121-108 SCRAMBLER

*** IMPORTANT ***

PLEASE RETAIN THIS INSTRUCTION SHEET IN YOUR FILES. IT CONTAINS IMPORTANT REPLACEMENT PARTS INFORMATION. ALL EQUIPMENT SHOULD BE INSTALLED IN ACCORDANCE WITH THESE INSTRUCTIONS.

IT IS IMPORTANT TO USE AND MAINTAIN ALL PUBLIC PLAYGROUND EQUIPMENT PROPERLY. PLAYGROUND EQUIPMENT, WHICH IS IMPROPERLY MAINTAINED, CAN CAUSE SERIOUS INJURY. PERIODICAL INSPECTIONS, MAINTENANCE, REPAIR AND/OR REPLACEMENT OF DAMAGED PARTS IS NECESSARY FOR SAFE OPERATION OF EQUIPMENT AND SAFETY OF USERS. RESILIENT SURFACING SHOULD BE USED UNDER ALL PLAYGROUND EQUIPMENT. APPROPRIATE PUBLICATIONS, AVAILABLE AT NO CHARGE, FROM THE CONSUMER PRODUCT SAFETY COMMISSION, INCLUDE "A HANDBOOK FOR PUBLIC PLAYGROUND SAFETY." YOU CAN RECEIVE YOUR FREE COPY BY CALLING 1-301-504-7908.



PACKING LIST

1 CTN	-1	Hardware	Bag
1 CTN	-2	103-141	Net
1 BDL	1	103-202	Net Bar
	-2	503-622	Post 2 3/8" x 9" LG

HARDWARE BAG



2	-	503-501	2 3/8" Elbow
4	-	503-637	Net Anchor
18	-	585-901	S-Hook
4	-	196-802	1/2" x 1/2" Socket Set Screw
1	-	805-532	Warning Labels
1	-	805-534	SportsPlay Label
1	-		Maintenance Checklist

2 CTN	1 BDL	3 TOTAL PCS	WT 140#	CLASS 70
-------	-------	-------------	---------	----------



121-108 SCRAMBLER

GENERAL USE/FALL ZONE & FOOTING RECOMMENDATIONS

STATIONARY & PORTABLE EQUIPMENT - USE/FALL ZONES SHOULD EXTEND A MINIMUM OF 6 FEET IN ALL DIRECTIONS FROM THE PERIMETER OF THE EQUIPMENT GROUND SPACE. THIS AREA SHOULD BE COVERED WITH THE REQUIRED AMOUNT OF RESILIENT SAFETY SURFACING MATERIAL. FOR SOME EQUIPMENT - USE/FALL ZONES CAN OVERLAP. SEE CONSUMER PRODUCT SAFETY COMMISSION GUIDELINES. DIAMETER & DEPTH OF FOOTINGS ILLUSTRATED ARE SATISFACTORY IN MOST APPLICATIONS FOR PIPE SIZES UP TO 2 3/8" DIAMETER. VARYING SOIL & CLIMATIC CONDITIONS MAY REQUIRE DEEPER & HEAVIER FOOTING IN SOME AREAS. CHECK LOCAL BUILDING CODES.




- If resilient surfacing is to be less than 12", then additional pipe should be put in concrete to maintain proper finish grade for equipment.



Suggested Bracing Method

USE AREA & FOOTING:

USE AREA = 17x19'



121-108 SCRAMBLER

Page 3
Rev 06/20/03

GENERAL ASSEMBLY INSTRUCTIONS:


Check all the parts and hardware with the packing list to be sure you have received everything needed to assemble this product. CONTACT YOUR LOCAL DISTRIBUTOR WITH NOTIFICATION OF ANY MISSING OR DAMAGED PARTS. Contact must be made within ten days of receipt of your order. Only hand-tighten nuts & bolts on initial assembly. Final tightening should be done EVENLY after final assembly when unit has been plumbed and leveled. After assembly is complete, ANY ENDS OF BOLTS PROTRUDING BEYOND NUTS SHOULD BE CUT OFF AND/OR PEENED OVER TO REMOVE ANY SHARP PROJECTIONS. Go over entire unit to file smooth any sharp edges or projections that may have been caused by rough handling in shipping or installation. T-Clamps are designed for both one and two bolt connections. In many situations only one bolt is required. See specific assembly instructions. On products with platforms installed 1 - 2 degrees off level to facilitate water drainage.

GENERAL MAINTENANCE INSTRUCTIONS:


Check MONTHLY for loose bolts, damaged or broken parts. Tighten and/or replace immediately.

SPECIFIC ASSEMBLY INSTRUCTIONS:

- STEP #1: Mark & Dig footing holes per SKETCH on PAGE #2.
STEP #2: Lying on the ground, attach Elbows to each end of Net Bar.



- STEP #3: Attach Post to each end of Elbows.




- STEP #4: Assemble Nets to Net Bar with S-Hooks

Note: Make sure ends of S-HOOKS are CLOSED



- STEP #5: Stand upright & brace Net Assy. & Net Anchors in footing holes. Attach Brace to legs to proper height. Length of pipe below intended level of Resilient Surfacing should be 24". Tops of Net Anchors should be just above ground level, so Resilient Surfacing will cover them.
STEP #6: Pour Concrete. Wait 48 hours before attaching net to Net Anchors. Make sure ends of S-HOOKS are CLOSED.



- STEP #7: Plumb and level entire unit. Tighten all nuts & bolts so that lock washers are flat. Remove braces; add resilient surfacing before using equipment.
STEP #8: Attach Warning Label and Manufacturer's Identification Label to a clean surface. The Labels should be attached in a location where they are clearly visible and legible and away from normal hand and foot placement areas. The Labels must be replaced if they become illegible, destroyed, or removed. Contact your Distributor for replacement Labels.