




Fixit with Air Kit 2



Fixit with Air Kit 3



Minimum Footprint



Capacity 1 Bike

Materials



Main body: 6.308 x .154" tube
 Bike Hanger: 1.5" sch. 40 pipe, 1/4" plate
 Foot: 10" dia. x .25" plate
 Tool tethers: 5/32" stainless steel cable
 Manual air pump
 Hand tools:
 Philips and flat head screwdrivers
 2.5, 3, 4, 5, 6, 8mm Allen wrenches
 Headset wrench
 Pedal wrench
 8, 9, 10, 11mm box wrenches
 Tire levers (2)

Finishes



An after fabrication hot dipped galvanized finish is our standard option. 250 TGIC powder coat colors are also available.

Our powder coat finish assures a high level of adhesion and durability by following these steps:

1. Sandblast
2. Epoxy primer electrostatically applied
3. Final thick TGIC polyester powder coat

Installation Methods



Foot Mount has 10" diameter x.25" foot with four anchors per foot.

Space Use and Setbacks



Wall Setbacks:

The back of the Fixit should be 12" from wall. Both sides of the Fixit should be at least 45" from walls or other obstructions. No part of the Fixit should protrude into a walkway, bike lane, or common area.

Street Setbacks:

For Fixits running parallel to the street, a 60" setback is recommended. For Fixits installed perpendicular to the street, a 60" setback is the minimum.