

TERRA BOUND



SOLUTIONS

20020 Hickory Twig Way • Spring, Texas 77388

Phone: 281-288-6693 • Fax: 281-288-2870

Email: contact@terraboundsolutions.com • Web: www.terraboundsolutions.com

Recommended Crew:

Minimum 1-2 People

Tools Required for Assembly:

T-30 TORX Bit

3/16" x 6" Drill Bit

Post Hole Digger / Shovel / Auger

Tape Measure

Level

High Speed 3/8" electric drill w/ clutch

Installation Time:

6 to 8 hours

Concrete Required:

1.8 cu ft. per post

Note: Concrete must have a minimum rating of 2,500 psi and must be mixed per manufacturers recommendation.

This space intentionally left blank.

Standard Hardware

5/16" x 5"
RSS Stainless




5/16" x 4"
RSS Stainless

5/16" x 3-1/8"
RSS Stainless

5/16" x 2-1/2"
RSS Stainless

1/4" x 2-1/2"
RSS Stainless

#10 x 2-1/2"
R4 Stainless



NOT TO SCALE!

Pre-Installation Check


Check off all items received, against the packing list. Notify your local sales representative immediately of any items that are missing or that may be damaged.

TERRABOUND IS NOT RESPONSIBLE
FOR ITEMS DISCOVERED MISSING
AFTER 72 HOURS FROM TIME OF
DELIVERY.

**PRE-DRILLING IS REQUIRED. ALL LOCATIONS WHERE
HARDWARE IS TO BE FASTENED REQUIRES PRE-
DRILLING TO ENSURE PROPER INSTALLATION AND
STRUCTURAL INTEGRITY. WE ARE NOT RESPONSIBLE
FOR INSTALLATION OR STRUCTURAL ISSUES THAT
ARISE FROM NOT PRE-DRILLING ATTACHMENTS.**


This space intentionally left blank.

Kennel Club Deluxe Components




Kennel Club Post Footers

When beginning the Kennel Club assembly, use the footer reference below to mark where your post holes will be. The footer holes should be 12" in diameter by 18" deep. **It is highly recommended the concrete not be set until the completion of the Kennel Club assembly. A dry fit of the posts and deck configuration is recommended to ensure an accurate and easy installation.**





Kennel Club Deluxe Assembly

Once your posts are in dry fitted and placed in the footer holes, begin to install the Kennel Club deck platforms as shown below. The deck heights should be installed so that the tops of the deck surface should be 40" from the ground surface.



Kennel Club Deluxe Assembly (Contd.)


Supporting the deck from underneath, fasten the platform using (8) 5/16" x 3-1/8" RSS screws (2 per corner) through the 2x3 deck frame and into the 4x4 post. Repeat the previous steps on the remaining deck platform.



5/16" x 3-1/8" RSS Screw

Kennel Club Assembly (Contd.)


With the deck platforms in place proceed to fasten the Dog House Crawl panels to the 4x4 posts as shown below. The panels are placed behind the 4x4 posts so that the outside edges of the panels are flush with the outside edges of the 4x4 posts (A). The tops of the panels rest directly up against the underside of the deck platform frame (B). With the panels in place fasten (6) 2-1/2" RSS Screws (3 per side) through the Dog House Crawl panel and into the 4x4 posts. Repeat the previous steps on the remaining Dog House Crawl Panel until all are fastened in place.



5/16" x 2-1/2" RSS Screw

Kennel Club Assembly (Contd.)


Proceed to place the Dog Barrier panels in the locations as shown below. The bottoms of the barriers should be placed 1-1/2" to 2" above the surface of the deck platform. The outside edges of the panels (C) should align flush with the outside of the 4x4 posts. Once in place fasten (4) 5/16" x 2-1/2" RSS Screws (2 per side) through the barrier panel and into the post.



5/16" x 2-1/2" RSS Screw

Kennel Club Assembly (Contd.)


The 24" Diameter Crawl Tunnel is mounted directly to the 4x4 posts using (8) 5/16" x 4" RSS screws. Pre-drill through the panel plastic (D) with a 1/4" bit and into the post, then proceed to fasten one 5/16" x 4" RSS screw per corner, through the panel and into the post as shown below.



5/16" x 4" RSS Screw


Kennel Club Assembly Paws-Trek Ramp

Center the Paws-Trek Ramp between the posts and ensure that the top of the ramp is flush with the top of the deck platform.



Kennel Club Assembly Paws-Trek Ramp (Contd.)


Once the Paws-Trek climber is centered and flush, pre-drill through the deck platform at the approximate locations shown below with a 3/8" bit. Drill through the underside of the deck and through the HDPE of the Paws-Trek ramp. Fasten (2) 3/8" x 3" button head bolts through the pre-drilled holes and tighten with a 3/8" nylon lock nut. Fasten (2) 5/16" x 3-1/8" RSS screws (1 per leg) through the outside of the frame (E) and into the 2x3 leg support (D).



Kennel Club Standard Ramp Assembly (Contd.)

Locate the ramps and place them so that the ears of the mounting board are flushed to the outside face of the 4x4's. The top of the mounting board should be positioned flush with the top of the deck platform surface. With the ramp in the proper position and height fasten (4) 5/16" x 3-1/8" RSS screws (2 per side) through the mounting board and into the 4x4 posts.

Repeat this step for the remaining ramp.




5/16" x 3-1/8" RSS Screw

Kennel Club Standard Ramp Assembly (Contd.)

With the ramp attached at the top, fasten the (2) 2x3 support legs to the inside support frame of the ramp as shown below. The 2x3 legs will also require a footer hole the same dimensional specifications as mentioned on page 5.


Fasten (4) 5/16" x 3-1/8" RSS screws (1 per leg) through the outside of the frame and into the 2x3 leg support. Repeat the same steps on the remaining ramp.



5/16" x 3-1/8" RSS Screw



Kennel Club Deluxe Assembly (Contd.)

Proceed to fasten the middle deck platforms. These platforms will need to be installed at a 32" height. Refer to page 7 for deck platform installation step.



Kennel Club Filler Block/Kickplate Assembly (Contd.)


To prevent a dog from getting their head or body stuck between the platforms, the use of a filler block and kickplate is necessary (F). Fasten (4) 5/16" x 3-1/8" RSS Screws through the Kickplate HDPE and into the 4x4 post.



5/16" x 3-1/8" RSS Screw

Kennel Club Filler Block/Kickplate Assembly (Contd.)


To fasten the Filler Block, fasten (2) 5/16" x 3-1/8" RSS Screws through the underside of the deck at the approximate locations shown below and into the filler block.



5/16" x 3-1/8" RSS Screw


Kennel Club Deluxe Assembly (Contd.)

Proceed to fasten the Dog Hoop Panels (G), Dog Bone Barriers (H), additional Filler Blocks (I), and last two Deck Platforms (J).



Kennel Club Rover Arch Bridge Assembly



Proceed to place the Rover Arch Bridge between the posts as shown below. The bottom of the bridge will rest on the tops of the platforms. Once in place, fasten (8) 5/16" x 3-1/8" RSS Screw through the underside of the bridge and into the posts, two in each corner location as shown below.



5/16" x 3-1/8" RSS Screw

Kennel Club Rover Arch Bridge Assembly (Contd.)

After the bridge is in place, locate the Bridge Barrier Panels and place them between the posts as shown below. The inside edge of the panel (K) should lie flush with the inside face of the posts(L). Once in place, fasten (8) 5/16" x 3-1/8" RSS Screws through the 2x3 brackets (M) and into the posts as shown below.






5/16" x 3-1/8" RSS Screw

Kennel Club Rover Leap Bar Assembly (Contd.)

The dog leap bars can be installed at the height preferred by the owner based on the agility level of the dog(s). The measurement below is a guide only and can be adjusted as necessary.


The placement of the leap bars should be centered on to the 4x4 post. Proceed fasten the Leap Bars to the 4x4 posts using (4) 5/16" x 3-1/8" RSS Screw (2 per side) through the leap bar collar and into the 4x4 post.



5/16" x 3-1/8" RSS Screw


Kennel Club Dog Bone Room Assembly (Contd.)

Place the Dog Bone A-frame Roof on top of the (4) 10' posts. The roof should be installed so that the tops of the 4x4 posts align with the tops of the A-Frame roof side support (N). Ensure that it is level and plumb before proceeding to fasten in place.



Kennel Club Dog Bone Room Assembly (Contd.)

With the roof in place proceed to fasten (4) 5/16" x 3-1/8" RSS Screws (1 per side) through the pre-drilled holes shown below and into the 4x4 posts. Repeat this step for the remaining roof.



5/16" x 3-1/8" RSS Screw