


PRODUCT ASSEMBLY INSTRUCTIONS • ITEM# D006/D022 DOG WASTE STATION

D006 • DOG WASTE STATION

PARTS LIST:

- Can (1)
- Post (1)
- Dispenser (1)
- Sign/Sign Bracket (1)
- Dispenser Keys (2)
- 600 Waste Bags
- 50 Can Liners
- Hardware Pack



CAN (1)



DISPENSER (1)



HARDWARE (1)



POST* (1)

*2 Post Sections 45" Each

ASSEMBLY ON REVERSE

DOG WASTE STATION



SIGN(1) + BRACKET(1)



600 WASTE BAGS



50 CAN LINERS

NUTS & BOLTS LIST:

- 3" Bolt (2)
- 2" Bolt (3)
- 1" Bolt (2)
- Flat Washers (6)
- Split-Lock Washer (6)
- Hex Nuts (6)



• Flat Washers (6)



• Split-Lock Washer (6)




• Hex Nuts (6)



ITEM# D006 DOG WASTE STATION ASSEMBLY INSTRUCTIONS

1. ASSEMBLE POST: overlap post one tapered-end 6" onto the flat end of post two. Thread 2 bolts (C) with 2 flat washers (D) to connect. Tighten with nuts and lock washers (E, F).
2. Mark Assembled Post 18" from tapered end: bury the post in concrete level to 18" mark.
3. ATTACH CAN: Install 6" above ground; thread the 2 bolts (A) with 2 flat washers (D) through the can from the inside. Line up the bolts with holes in the post (6" above ground) and thread through. Tighten with nuts and lock washers (E, F).
4. ATTACH DISPENSER: Open the DISPENSER. Align the SIGN BRACKET's long slot with the top 2 holes of the dispenser and use 2 bolts (B) & flat washers (D) from the INSIDE of the dispenser to bolt thru the bracket, thru the post and secure in the back of the post with lock washer (E) and nuts (F). (see diagram)
Use a third bolt (B), flat washer (D), & lock washer (E) & nut (F) at the bottom hole of the dispenser to attach to post.
5. ATTACH SIGN: Bolt sign to the top of the SIGN BRACKET and secure with washers, lock washers and nuts.
6. Fill Dispenser with bags, and install can liner.



PRODUCT ASSEMBLY INSTRUCTIONS • SIGN & SIGN BRACKET



SIGN(1)



BRACKET(1)




All required hardware is in hardware pack


Note: use Dispenser Upper bolt (step 4), washer, & nut for bottom "slotted" hole.

SIGN ASSEMBLY INSTRUCTIONS


A. Align all matching holes.



B. Place bolts through all 4 locations.



C. Tighten all nuts and bolts.



NOTE: Final product should have the Sign Bracket "sandwiched" between the Dispenser and the Post.